

Quick Install Guide

For setup with your smartphone and tablet



Runtastic LIBRA



Workouts and diets can be challenging, so let's have an easy start!

1. Insert AAA batteries!

2. Download app:
www.runtastic.com/apps/libra



3. Get connected!



DE

Installationsanleitung

Lege die mitgelieferten 3 Stück AAA Batterien in die Waage ein.
Verwende die mitgelieferten Teppichfüße auf einem Teppichboden.
Lade dir die kostenlose Runtastic Libra App aus dem App Store herunter.
Starte nun die Runtastic Libra App und folge den Anweisungen.

EN

Setup instructions

Insert the 3 included AAA batteries.
Attach the included carpet feet when using the scale on a carpet.
Download the free Runtastic Libra app from the App Store.
Start the Runtastic Libra app and follow the instructions.

FR

Guide d'installation

Installez les trois piles AAA incluses dans la balance.
Rajoutez les pieds d'appoints inclus si vous utilisez la balance sur une moquette.
Téléchargez l'application gratuite Runtastic Libra depuis l'App Store.
Démarrez l'application et suivez les instructions.

IT

Istruzioni

Inserisci le 3 pile AAA contenute nella confezione della bilancia.
Attacca i distanziali contenuti nella confezione per usare la bilancia sul tappeto.
Scarica l'applicazione gratuita Runtastic Libra dall'App Store.
Lancia l'applicazione Runtastic Libra e segui le istruzioni.

ES

Instrucciones de instalación

Introduce las 3 pilas AAA incluidas en la báscula.
Monta los pies incluidos para usar la báscula encima de una alfombra.
Descarga la app gratuita Runtastic Libra en la App Store.
Abre la app Runtastic Libra y sigue las instrucciones.

DK

Brugsanvisning

Sæt de 3 medfølgende AAA-batterier i.
Fastgør de medfølgende tæppe fødder, når du bruger vægten på et tæppe.
Download den gratis Runtastic Libra app fra App Store.
Start Runtastic Libra app og følg vejledningen.

NO

Instruksjon

Sett inn de 3 medfølgende AAA batteriene.
Fest de medfølgende teppeføttene når vekten benyttes på et teppe.
Last ned gratis Runtastic Libra App fra App Store.
Start Runtastic Libra app og følg instruksjonene.

SE

Installation och instruktioner

Sätt i de medföljande batterierna (3x AAA-batterier).
Fäst de medföljande fötterna om vågen skall stå på en matta.
Ladda ner gratis-Appen Runtastic Libra app från App Store.
Starta Runtastic Libra app och följ instruktionerna.

RU

Инструкция по установке

Установи 3 прилагающиеся батарейки.

Используй прилагающиеся насадки на ковровом покрытии.

Загрузи бесплатное приложение в он-лайн магазине App Store.

Запусти приложение Runtastic Libra App и следуй указаниям.

NL

Installatiehandleiding

Leg de meegeleverde 3 stuks AAA batterijen in het batterijvak van de weegschaal.

Gebruik de meegeleverde opzetstukken voor het wegen op een tapijt.

Download de gratis Runtastic Libra app uit de App Store.

Start nu de Runtastic Libra app en volg de aanwijzingen.

FI

Asennusohjeet

Aseta paikoilleen 3 laitteen mukana tullutta AAA-paristoa.

Kiinnitä mukana tulleet jalat, kun käytät vaakaa matolla.

Lataa ilmainen Runtastic Libra –sovellus App Storesta.

Käynnistä Runtastic Libra –sovellus ja seuraa ohjeita.

PT

Instruções

Introduz / Coloque as baterias AAA incluídas na escala.

Monta pés incluído para usar a escala sobre um tapete.

Baixar do aplicativo gratuito escala Runtastic na App Store.

Abre o aplicativo Runtastic Libra e siga as instruções.

FCC Compliance Statement (For US)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

Operating temperature: +41°F to +104°F (+5°C to +40°C)

Operating humidity: 20 to 95% RH

BATTERY WARNING

- Always keep batteries out of the reach of children. Batteries can be life threatening if swallowed. Therefore, keep the batteries and scale out of the reach of small children. If a battery is swallowed, medical assistance should be obtained immediately.
- Remove a drained battery from the scale promptly, otherwise it can leak. In this case avoid contact with skin, eyes and mucous membranes. Rinse any areas affected by battery acid immediately with plenty of clear water, and seek medical assistance immediately.

CAUTION

- Batteries may not be charged or reactivated by other means, taken apart, thrown into fire or short circuited.
- If necessary, clean the battery contacts and also the counter contacts in the device.
- Danger of explosion if the battery is replaced incorrectly.
- Batteries are to be inserted with correct polarity.
- Never mix old and new batteries (replace all batteries at the same time).
- Never mix Alkaline, standard or re-chargeable batteries.

- Use only batteries of the same or equivalent types as recommended.
- Do not recharge non-rechargeable batteries.
- Never expose the batteries to excessive heat such as sunshine, fire or similar! Non-adherence to these instructions can lead to damage and sometimes even explosion of the batteries.

NOTICE

- Clean the batteries contacts and also those of the product prior to batteries installation.
- The supply terminals are not to be short-circuited.
- Always remove exhausted or dead batteries.
- Remove the battery from the scale when not being used for long periods of time.
- Batteries can contain toxins that are harmful to health and the environment. Always dispose of batteries in accordance with applicable local regulation. Do not dispose of batteries with normal household waste.



The scale should not be used by individuals with medical implants (i.e. pacemakers). The function of the implanted device may be impaired.

The scale is not to be used during pregnancy.

Not intended for use by children under 10.

Declaration of conformity

EMC Directive 2004/108/EC, R&TTE Directive 1999/5/EC, RoHS Directive 2011/65/EU:

Short text of the conformity declaration: Krippel-Watches hereby declares that the Bluetooth scale (RUNSCA1) complies with the basic requirements and the other relevant provisions of the EMC Directive 2004/108/EC, RoHS Directive 2011/65/EU and the remaining relevant conditions of the R&TTE Directive 1999/5/EC. You can access the full text of the conformity declaration on our homepage: www.runtastic.com/products

